

PRODUCT COVERAGE ESTIMATOR

Approximate square foot coverages for the typical job, per gallon, based on substrate type. Two coats are assumed for substrates where two coats are typical, and are factored in. As with any job dealing with natural stone varied results can be expected.

SEALERS

	Travertine	Limestone	Marble	Travertine Tumbled	Limestone Tumbled	Marble Tumbled	Granite	Slate	Quartzite	Sandstone	Flagstone	Terra Cotta	Saltillo Tile	Grout	Brick/Masonry	Concrete
Tech Seal solvent	1500	1500	1500	900	900	900	1500	900	1000	500	500	600	600	2000	500	500
Max Guard water	1500	1500	1500	900	900	900	■	900	1000	500	500	600	600	2000	500	500
Select Seal water	1500	1500	1500	900	900	900	■	900	1000	500	500	600	600	2000	500	500
Rapid Seal water	1500	1500	1500	900	900	900	■	900	1000	500	500	600	600	2000	500	500
Grout Sealer Pro	1500	1500	1500	900	900	900	■	900	1000	500	500	600	600	2000	500	500
Preserve solvent	1500	1500	1500	900	900	900	1500	900	1000	500	500	600	600	2000	500	500
Paver & Masonry Sealer	1500	1500	1500	900	900	900	■	900	1000	500	500	600	600	2000	500	500
Reveal & Seal solvent	1500	1500	1500	900	900	900	1500	900	1000	500	500	600	600	2000	500	500
Enhancer water	1500	1500	1500	900	900	900	■	900	1000	500	500	600	600	2000	500	500
Shine & Seal	■	■	■	600	600	600	*800	700	900	250	250	300	300	■	250	250
Barrier EXT	■	■	■	600	600	600	*800	700	900	250	250	300	300	■	250	250

*Only used on unpolished instances of this substrate

	8oz	16oz	Gallon
1 x 1*	20	50	450
6 x 6	250	500	4000
12 x 12	500	1000	8000
16 x 16	600	1200	9600
18 x 18	700	1400	11200
20 x 20	800	1600	12800

*Coverage based on commercial application also known as the squeegee method.

CLEANERS

	Travertine	Limestone	Marble	Travertine Tumbled	Limestone Tumbled	Marble Tumbled	Granite	Slate	Quartzite	Sandstone	Flagstone	Terra Cotta	Saltillo Tile	Grout	Brick/Masonry	Concrete
Ultra Clean	■	■	■	■	■	■	■	1200	■	1000	1000	1000	1000	2000	1000	900
Modern Clean	2000	2000	2000	2000	2000	2000	2000	1200	1000	1000	1000	1000	1000	2000	1000	900
Easy Etch	■	■	■	■	■	■	■	■	■	■	■	■	1500	■	*600	
Revive	■	■	■	■	■	■	■	■	■	■	■	■	1500	■	*600	
Scorch	■	■	■	■	■	■	■	1200	■	1000	1000	1000	1000	2000	1000	900
Balance	5000	5000	5000	5000	5000	5000	5000	4000	4000	4000	4000	4000	4000	5000	4000	3500

*Etches surface in preparation of coatings

Powders

	Travertine	Limestone	Marble	Travertine Tumbled	Limestone Tumbled	Marble Tumbled	Granite	Slate	Quartzite	Sandstone	Flagstone	Terra Cotta	Saltillo Tile	Grout	Brick/Masonry	Concrete
Hone 150	500	500	500	500	500	500	■	■	500	■	■	■	■	■	■	500
Hone 400	600	600	600	600	600	600	■	■	600	■	■	■	■	■	■	600
Hone 800	700	700	700	700	700	700	■	■	700	■	■	■	■	■	■	700
Hone 1200	700	700	700	700	700	700	■	■	700	■	■	■	■	■	■	700
Jazz	700	700	700	700	700	700	■	■	■	■	■	■	■	■	■	700
Outshine	700	700	700	700	700	700	■	■	■	■	■	■	■	■	■	■

Pads

	Travertine	Limestone	Marble	Travertine Tumbled	Limestone Tumbled	Marble Tumbled	Granite	Slate	Quartzite	Sandstone	Flagstone	Terra Cotta	Saltillo Tile	Grout	Brick/Masonry	Concrete
Coarse	600	600	600	600	600	600	■	■	600	■	■	■	■	■	■	600
Hone	1000	1000	1000	1000	1000	1000	■	■	1000	■	■	■	■	■	■	1000
Satin	1200	1200	1200	1200	1200	1200	■	■	1200	■	■	■	■	■	■	1200
Shine	1500	1500	1500	1500	1500	1500	■	■	1500	■	■	■	■	■	■	1500



MODERN STONE
TECHNOLOGIES